

AT 400 S2 / AT 400 CI

PIEZA N°	CÓDIGO	DESCRIPCIÓN	MODELO	CANT.X MAQ.
1	001012	TORN.IZQ.MANDRIL AT400	AT400CI	1
2	AR1038	MANDRIL 10 MM. AT400	AT400S2-CI	1
3	001002	TORN.CABEZAL AT400	AT400S2-CI	4
4	010002	CABEZAL AT400	AT400S2-CI	1
5	002007	ROD.CABEZAL AT400 (6201)	AT400S2-CI	1
6	017002	ANILLO SEG.CABEZAL AT400	AT400S2-CI	1
7	003002	EJE SALIDA C/ENG. AT400	AT400S2-CI	1
8	020010	BUJE TAPA INTERMEDIA AT400	AT400S2-CI	1
9	009002	TAPA INTERMEDIA AT400	AT400S2-CI	1
10	001004	TORN.TAPA MOTOR AT400	AT400S2-CI	4
11	017022	ARAND.COMP.AT400	AT400S2-CI	1
12	002004	ROD.ROTOR DELANTERO AT400 (608)	AT400S2-CI	1
13A	006002	ROTOR C/VENT.AT400	AT400S2-CI	1
13B	013002	VENTILADOR AT400	AT400S2-CI	1
14	011002	DEFLECTOR AT400	AT400S2-CI	1
15	001006	TORN.ESTATOR AT400	AT400S2-CI	2
16	005002	ESTATOR AT400	AT400S2-CI	1
17	002006	ROD.ROTOR TRASERO AT400 (607)	AT400S2-CI	1
18	007002	CUERPO MOTOR AT400	AT400S2-CI	1
19	015002	ESCOBILLA (JUEGO) AT400	AT400S2-CI	1
20	016002	PORTA ESCOBILLA AT400	AT400S2-CI	2
21	008002	TAPA MANGO AT400	AT400S2-CI	1
22	001008	TORN.TAPA CUERPO AT400	AT400S2-CI	2
23	014004	INTERRUPTOR VVR AT400CI	AT400CI	1
24	001010	TORN.TAPA CUERPO CORTO AT400	AT400S2-CI	2
25	019002	CABLE SALIDA AT400	AT400S2-CI	1
26	021010	GANCHO COLGAR AT400	AT400S2-CI	1
	ARLLS2	LLAVE MANDRIL AT400	AT400S2-CI	1

23	014002	INTERRUPTOR 2V AT400S2	AT400S2	1
----	--------	------------------------	---------	---

AT 400 S2 - AT 400 CI_Explosión

